

Attention!

When working on breakerless transistorized ignition system be sure to observe the following points:

- Persons with heart stimulators should not work on such ignition systems.
- With the engine running or at starting speed, do not touch, pull off etc. components of ignition system e.g. ignition cable, ignition coil, spark plug connector.
- Perform assembly jobs on ignition system only with engine stopped and ignition switched off.

Also connect and disconnect testers only with engine stopped and ignition switched off (15—531).

- Do not install adapters or transmitters, e.g. for stroboscope, into ignition cable, e.g. cylinder 1, which are metallically bright externally.